

This is a sample manual



Goto:

[dubmanuals.com](http://dubmanuals.com)

to download the complete manual

Note, the Table of Contents links  
may not function in this sample

# Owner's Manual

## 1996 Golf & GTI Models



## TABLE OF CONTENTS

### CONTROLS AND EQUIPMENT

General illustration	6
Warning and indicator lights	8
Keys, Power locks	10, 12
Anti-theft alarm system	14
Doors, Rear lid	15, 16
Power Windows, Mirrors	17, 19
Safety belts	20
Air bag system	30
Child safety	36
Head restraints	43
Front seats	44
Rear seat	46
Luggage compartment	49
Filler panel	49
Pedals, Parking brake lever	50
Automatic transmission	51
Manual transmission	56
Tilt steering wheel	57
Steering lock/Ignition/Starter switch	58
Starting procedures	59
Stopping engine	61
Instrument cluster	62
Warning / Indicator lights	67
Switches	74
Turn signals/Headlight dimmer switch lever	78
Cruise control	79
Wiper and washer system	80
Air conditioning	82
Power roof	88
Lockable compartment, Sun visors	89
Interior lights,	90
Beverage holder, Coat hooks,	91
Ashtrays, Cigarette lighter	92
Roof rack / Roof railings	93

### VEHICLE OPERATION

The first 1,000 miles (1,500 km) - and afterwards	94
Operate your vehicle safely	95
Operate your vehicle economically and minimize pollution	97
Braking	101
Trailer towing	104